

# How to ENABLE/DISABLE GPS function?

- a. Open AT command port (Please refer to [Slide 2](#))
- b. Send the commands below (Software control, ignore GPS\_ENABLE pin ):

```
//Disable GPS
```

```
AT!ENTERCND="A710"
```

```
AT!CUSTOM="GPSENABLE",0
```

```
AT!RESET
```

```
//Enable GPS
```

```
AT!ENTERCND="A710"
```

```
AT!CUSTOM="GPSENABLE",1
```

```
AT!RESET
```

Send the commands below for GPS\_ENABLE hardware pin control:

```
//Enable GPS
```

```
AT!ENTERCND="A710"
```

```
AT!CUSTOM="GPSENABLE",4
```

```
AT!RESET
```

# How to use AT command for SDX55 chipset on Windows (EM91 Series/EM7690)?

- For MBPW Release 31 or newer, please add “**EnableUDE=1**” in configuration.ini, then install the driver.
- Open Device Manager and find **Modem Port**
- Right click -> properties -> Modem -> Port: COMx
- The example is COM13

