

## How to stream NMEA data for SDX55 chipset on Linux (EM91 Series/EM7690)?

- Download the MBPL\_SDK\_R32\_ENG2-lite.bin.tar from the following link: [Mobile Broadband Package for Linux \(SDK, Drivers, Documentation\)](#)
- Path on Linux: \MBPL\_SDK\_R32\_ENG2-lite.bin.tar\MBPL\_SDK\_R32\_ENG2-lite.bin\SampleApps\lite-qmi-loc
- Refer to section 8. Instruction on how to stream NMEA sentences to a Virtual Serial Port (VSP) located in the package MBPL\_SDK\_R32\_ENG2-lite.bin.tar.



lite-qmi-loc-readme.txt